



Limpiador Lavavajillas 354 ml

Dishwasher Cleaner & Disinfectant

SKU BlueHome P1830758630209595 · Glisten · 354 ml (12 oz) · Cuidado del Hogar

Para qué es · What it's for

Limpia y desinfecta tu lavavajillas por dentro, una vez al mes. Cleans and disinfects your dishwasher inside, once a month.

Listo para Huéspedes · Guest-Ready · Elecciones Conscientes · Conscious Choices

Español	English
Qué es. Limpiador y desinfectante para el interior del lavavajillas. Rompe la cal, la grasa, el óxido y los residuos de comida y detergente en el tambor, los brazos rociadores, los filtros y las tuberías, y desinfecta contra bacterias como E. coli y Salmonella. Devuelve el rendimiento y deja la máquina higiénicamente limpia.	What it is. A cleaner and disinfectant for the inside of your dishwasher. It breaks down limescale, grease, rust and food and detergent buildup in the tub, spray arms, filters and pipes, and disinfects against bacteria such as E. coli and Salmonella. It restores performance and leaves the machine hygienically clean.
Dónde se usa. En todo tipo de lavavajillas, incluidos los de interior de acero inoxidable. Seguro para la tubería y para tanques sépticos.	Where to use it. In all dishwasher types, including those with stainless steel interiors. Safe for plumbing and septic systems.
Cómo se usa. 1. Usa la lavavajillas vacía y sin detergente. 2. Quita la tapa; no quites el sello de cera. Coloca la botella boca abajo en el cestillo de cubiertos o asegurada en la rejilla inferior. 3. Cierra y pon el ciclo más caliente (no uses eco ni rápido). El agua debe estar bien caliente para derretir el sello. 4. Al terminar, recicla la botella vacía. Úsalo una vez al mes o cuando haga falta.	How to use it. 1. Use the dishwasher empty and without detergent. 2. Remove the cap; do not remove the wax plug. Place the bottle upside down in the silverware basket or secured in the bottom rack. 3. Close it and run the hottest cycle (not eco or quick). The water must be hot enough to melt the plug. 4. When it finishes, recycle the empty bottle. Use once a month or as needed.

Cuidados · Care

Úsalo solo en la lavavajillas, no para la vajilla ni a mano. No lo uses con detergente ni con platos adentro; si quedaron platos por error, lávalos a mano. Guárdalo cerrado, en un lugar fresco y seco, fuera del alcance de niños y mascotas. Lee la etiqueta antes de usar. — Use it only in the dishwasher, not on dishes or by hand. Do not use it with detergent or with dishes inside; if dishes were left in by mistake, hand-wash them. Store it closed, in a cool, dry place, out of reach of children and pets. Read the label before use.

Amigable con el ambiente · Earth-friendly

Certificado EPA Safer Choice y registrado ante la EPA como limpiador y desinfectante. Seguro para tanques sépticos. Hecho en EE. UU. — EPA Safer Choice certified and EPA-registered as a cleaner and disinfectant. Septic-safe. Made in the USA.